


Hybrid inverter WiFi 2.0 Configuration Guide

» 1 Preface

WiFi 2.0 is a new generation of WiFi monitoring module from Sunways, with two modes: Bluetooth and WiFi. Bluetooth mode is mainly used for local monitoring and configuration of hybrid inverters, while WiFi mode is used for remote monitoring and configuration. The default mode is Bluetooth After hybrid inverter is connected to WiFi 2.0. Please read the following instructions carefully before use.

» 2 Bluetooth -WiFi Mode Switching Methods

There are two ways to switch between Bluetooth and WiFi mode. One is to switch quickly by pressing and holding button for 3 seconds when it is on the Home page; the other is to switch through the General Settings. The process is as follows:



» 3 Sunways Setup App Download Method


Sunways Setup APP is a mobile application that communicates with hybrid inverters over Bluetooth and allows you to monitor real-time status and configure parameters.

Scan the QR code to download and install the app.



» 4 configuration

- 1 Prepare a laptop, tablet or smart phone and turn on the wireless network function on the device.
- 2 Searching for the corresponding WLAN in the WLAN connection list" WiFi*****" ("*" represents digital), and tap connect.
- 3 The system information interface will automatically pop up; If not, manually open the browser and enter 10.10.100.254.



- 4 Tap "Scan" , A list of WiFi network names pop up.
- 5 Click and select the corresponding router network you want to configure.
- 6 Input the password of wireless network, (note the case difference), Tap"Connect".
- 7 If connected successfully "Connection succeeded"will displayed. After successful configure, the indicator status of WIFI 2.0 module will be steady on.

